



MASSE-CODES UND POSITIONEN/EARTH CODES AND LOCATIONS

G-1004 RH SCHEINWERFER BEFESTIGUNGSBLECH
RH HEADLAMP MOUNTING PANEL
G-1017 HALTER LENKSAEULE (HAUPTMASSE)
BRAKET STEERING COLUMN SUPPORT (MAIN EARTH)
G-1019 HALTER LENKSAEULE (ELEKTRONIK MASSE)
BRAKET STEERING COLUMN SUPPORT (ELECTRONIC EARTH)

LOTSTELLEN-CODES UND POSITIONEN/SOLDERED JOINT CODES AND LOCATIONS

S-105 IN 14406: NAEHE KRAFTSTOFFVORRATGEBER
IN 14406: NEAR FUEL TANK SENDER UNIT
S-1013 IN 14401: NAEHE ABGANG BOX
IN 14401: NEAR BOX
S-1014 IN 14401: NAEHE ABGANG MASSE HALTER LENKSAEULE
IN 14401: NEAR STEERING COLUMN EARTH BRACKET
S-1019 IN 14401: NAEHE ABGANG RH HAUPTSCHEINWERFER
IN 14401: NEAR RH HEAD LAMP
S-1028 IN 14401: NAEHE ABGANG RADIO
IN 14401: NEAR RADIO
S-1041 IN 14401: NAEHE ABGANG BEH.-HECKSCHEIBE SCHALTER
IN 14401: NEAR HEATED REAR WINDOW SWITCH
S-1054 IN 14401: NAEHE ABGANG BEH.-HECKSCHEIBE SCHALTER
IN 14401: NEAR HEATED REAR WINDOW SWITCH
S-1055 IN 14401: NAEHE ABGANG BEH.-HECKSCHEIBE SCHALTER
IN 14401: NEAR HEATED REAR WINDOW SWITCH
S-1060 IN 14401: NAEHE ABGANG BEL. REGEL WIDERSTAND
IN 14401: NEAR INSTR. PANEL ILL. CONTROL
S-1074 IN 14401: NAEHE ABGANG LH SCHLUSSLEUCHTE
IN 14401: NEAR LH COMBINED REAR LAMP

SERVICEFREUNDE DEUTSCHLAND